


ACTIVATING A WATER INTAKE WITH THE CARD

To activate the water intake, you must have already activated the electrical outlet. You must present the card again in front of the reader.



A beeping sound will be emitted again. You press the push button above the dispensing point, which will immediately activate the water dispensing.



To stop the distribution, you can **disconnect** your hose.

However, your distribution point will still be **active**.

To **deactivate** it, you must **present the card** in front of the reader, and as with activation, once the **beep has** been heard, **press the button** above the dispensing point to **stop it**.



Your water distribution point is now **disabled**. All you have to do is **start** the procedure again each time you use it to use your water credits.